

Roland®

MEMORY CARD
M-512G

RAM 64K BYTES

Use only in the products which M-512E is designated.

This card can also be used which instruments with use M-256E, M-256D or M-128D. (However, the amount of data that can be saved onto this card will be the same as when using a card originally specified for the instrument.)

INSTRUCTIONS

Copyright © 2002 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Before using this card, make sure to read the instructions below.

■ NOTES

- Never touch terminals. Also, avoid getting terminals dirty.
- Do not expose the card to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the card.
- To avoid possible breakdown, do not use the card in a wet area, such as an area exposed to rain or other moisture.
- To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the card.
 - Before you touch the card, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.
- Save the bag and the box in which the card was originally shipped, and put the card back into them whenever you need to store or transport it.
- Be sure that you are holding the card with the face up, and insert it slowly until it is securely in place.

- How to use the Memory Card is fully explained in the owner's manual of each device.

■ Battery Replacement

- When the display of your device using M-512G indicates a message such as "MEMORY CARD Battery Low" or "DATA Card Battery Low," the battery in M-512G card is nearly worn out. Please contact Roland Service Station for the battery replacement, referring to the owner's manual of your device.

⚠ WARNING Be sure to load all the data from the M-512G onto your device before the battery replacement. The data stored in your M-512G card may be lost while replacing the battery.

■ Protect Switch

The Protect Switch is provided to prevent accidental erasure of data. Please be sure to keep it in the ON position except when writing new data.

** In the interest of product improvement, the specifications and/or appearance of this card are subject to change without prior notice.*

Roland

MEMORY CARD
M-512G

RAM 64K BYTES

このカードは、使用可能なメモリー・カードとして、M-512Eが指定された機種のみにご使用ください。

なお、ローランド M-256E/M-256D/M-128Dが指定されている機種にも使うことができます。(ただしその場合、このカードに保存できるデータ量は、各機種で指定されているカードを使用したときと同じになります。)

取扱説明書

© 2002 ローランド株式会社

本書の一部、もしくは全部を無断で複製・転載することを禁じます。

このカードを使用する前に、以下の指示をよく読んでください。

ご注意

カードの端子の部分に触れたり、汚したりしないようにしてください。

直射日光の当たる場所や、発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。故障の原因になりますので、雨や水に濡れる場所で使用しないでください。

このカードは、静電気により部品が破壊される恐れがあります。カードを取り扱うときは、次の点に注意してください。

カードを持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっている静電気を放電してください。

カードを保管するとき、または輸送するときなどは、購入時にカードが入っていた袋(導電袋)および外箱に入れてください。

カードは差し込み方向を確認の上、確実に奥まで差し込んでください。

メモリー・カードにデータを記憶させる方法や使用方法は、各機器の取扱説明書をお読みください。

お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合もあります。

電池交換

使用機器側で「MEMORY CARD Battery Low」, 「DATA Card Battery Low」などのメッセージが表示されたら、メモリー・カードの電池が消耗しています。お買い上げ店またはローランド・サービスに電池交換を依頼してください。

⚠ 警告 電池交換の際には、メモリー・カード内のデータが失われることがありますので、あらかじめデータを使用機器等に記憶させてください。

プロテクト・スイッチ

プロテクト・スイッチは、メモリー・カードに保存されているデータを誤って消去しないように保護するためのものです。新しくデータを記憶させるとき以外は、オンにしておいてください。

製品の仕様および外観は、改良のため予告なく変更することがあります。

03016758

'02-8-C3-11N



This product complies with the requirements of European Directive 89/336/EEC.

For EU Countries