Roland SH-201 Cheat Sheet

Sound	**Filter Velocity**	Cancel+Cutoff		
	Amp Velocity	Cancel+Level		
	Pan	Cancel+KeyFollow		
	Overdrive	Overdrive+Level		
LFO	**KeyTrigger**	LFO+TempoSync	ON key retrigger	
	Fade In	LFO+Rate		
Delay	**HF Damp**	FX+Depth		
	Feedback	FX+Time		
	Mod Rate	FX+Amp ENV R		
	Mod Depth	FX+Amp ENV S		
Reverb	**High Cut**	FX+Depth		
	Predelay	FX+Time		
	Diffusion	FX+Flt ENV D		
	Density	FX+Flt ENV S		
	Size	FX+Flt ENV R		
	LF Damp Freq	FX+Amp ENV A		
	LF Damp Gain	FX+Amp ENV D		
	HF Damp Freq	FX+Amp ENV S		
	HF Damp Gain	FX+Amp ENV R		

	Delay	Reverb
1	Simple Delay	Room 1
2	1 Shot Delay	Room 2
3	Medium Delay	Studio 1
4	Long Delay	Studio 2
5	Analog Delay	Hall 1
6	Mod Delay	Hall 2
7	Chorus 1	Plate 1
8	Chorus 2	Plate 2

Patch Common	**Patch Level**	Cancel+FX Depth		
	Tone Balance	Cancel+Mix/Mod		
	Split Point	Cancel+Tap - Dual/Split+key - Cancel		
	Octave Shift	Lw/Up+OctUp/Down		
	Portamento Time	Portamento+Time(or 1-8 button)		
	Modulation	Cancel+Tap - User - BankA - 1-8		1 Pitch
				2 OSC1
				3 OSC2
				4 PW1
				5 PW2
				6 Filter
				7 Amp
				8 Audio-Flt
		Cancel+Tap - User - BankB - 1-3		1 Upper
				2 Lower
				3 Both
	D-Beam	Dbeam Flt/Assgn+knob/slider	Assign	
		Dbeam Flt/Assgn+Lw/Up	Destination	
		Cancel+DBeamExpress	Active Expression	
	Pitch Bend Range	Cancel+Tap - Lw/Up+key - Cancel		
		Cancel+Tap - User - BankC - 1-3		1 Upper
				2 Lower
				3 Both
	Expression	Cancel+Tap - User - BankD - 1-3		1 Upper
				2 Lower
				3 Both
Midi	**Rx/Tx Channel**	Cancel+Tap - Preset - BankA - 1-8	red	Ch 1-8
			green	Ch 19 - 16
	Midi-Thru	Cancel+Tap - Preset - BankC - 1-2		1 midi-USB Thru
				2 Soft Thru
	Midi Receive	Cancel+Tap - Preset - BankC - 3-4		3 Program Change
				4 Bank Select
	Midi Transmit	Cancel+Tap - Preset - BankC - 5-8		5 Program Change
				6 Bank Select
				7 Edit Data
				8 Active Sensing
Keyboard	**Master Tune**	Cancel+Pitch		
	Octave Shift	Lw/Up+OctUp/Down	octave shift	
	Transpose Value	Cancel+OctUp/Down	semitone shift	
	Patch Remain	Cancel+Tap - Preset - BankD - 1		
	Local On/Off	Cancel+Tap - Preset - BankD - 2		
	Midi Omni Mode	Cancel+Tap - Preset - BankD - 3	keyb disengage	
Pedal	**Pedal Polarity**	Cancel+Group(Preset/User)	Preset	standard
			User	reverse
	Pedal Assign	Cancel+(1-8)		1 Hold
				2 Modulation
				3 Volume
				4 Balance
				5 Pan
				6 Expression
				7 Start/Stop
				8 Arp-Sw
Sync	**Clock Source**	Cancel+Tap - Preset - BankB - 1-4		1 Patch
				2 System
				3 Midi
				4 USB
	Midi Sync Out	Cancel+Tap - Preset - Play/Stop		
	Metronome	Cancel+Tap - Preset - Rec+Bank		A Off
				B Rec-only
				C Rec&Play
				D Always
	Metronome Level	Cancel+Tap - Preset - Rec+(1-8)		
Others	**Device ID**	Cancel+Tap - Preset - Wide+(1-8)		1 17
				2 18
				3 19
				4 20
				5 21
				6 22
				7 23
				8 24