

GEM WS2II Workstation Keyboard & Expander Factory List

06.03.2012 by
www.deeppsonic.ch

VOICE	
000 x GRAND P	064 CELLO
001 x PIANO	065 HONKY
002 x RHODX	066 PICKRHD
003 x FMPNO	067 FMSYNTH
004 x VIBES	068 SINVIBE
005 G MARIMBA	069 SPACE_2
006 x CLAVI	070 WOWCLAV
007 x HARPSI	071 ROBOT
008 x GUITAR	072 SINGUIT
009 x JAZZGTR	073 JAZZYGTR
010 x LEADGTR	074 SPACE_3
011 x FUNKGTR	075 GUITePN
012 x A.BASS	076 DOUBLEB
013 x E.BASS	077 SINBASS
014 x FLANGED	078 SINVOX
015 x SLAP	079 PICK
016 x BRASS	080 SINBRAS
017 x T.SAX	081 SINSAX
018 x S.SAX	082 HARDSAX
019 x TROMB.	083 TRBORCH
020 x TRUMPET	084 TRUMP2
021 x FL.HORN	085 DETHORN
022 x FLUTE	086 FLUTE2
023 x OBOE	087 FUNVIBE
024 G ORGAN 1	088 ORGAN 8
025 G ORGAN 2	089 ORGAN 9
026 G ORGAN 3	090 ORGAN10
027 x PLECTRA	091 PLECTR2
028 x CHOIR	092 PKVOICE
029 x STRING	093 ATKSTRG
030 x BASS.pk	094 PLUCK
031 x DRUMS	095 SIN_MUT
032 x GRANDmf	096 REVPh
033 x GRANDff	097 SPACE_6
034 x RHODXff	098 STRANGE
035 x FMPNOMf	099 FMPICK
036 x FMPNOFF	100 HMPIANO
037 x GTR.fk	101 SPACE_5
038 x BRASSff	102 ATTKBRS
039 x HARP	103 SINHARP
040 x FUNKff	104 CLAVBRS
041 x STRINGf	105 CLAVORG
042 x FUNKCLA	106 CLAVPUL
043 BRASSsl	107 HAR_ACC
044 G SLOWSAW	108 HAR_SIN
045 SYNTH 2	109 MUT_ORG
046 x ORGAN 6	110 PUL_ORG
047 G TUBES	111 SAWPUL
048 x ACCORD	112 SYNTHPh
049 BANJO	113 BANJO2
050 BELLS	114 SINBELL
051 G SYNTH 1	115 CLUSTER
052 x CLARIN	116 SINCLAR
053 x ORGAN 4	117 ORGAN 7
054 HARMO	118 SPACE_4
055 G HORNS	119 SOFTHOR
056 x MUTED	120 SPACE_1
057 x PULSE	121 SOFTPUL
058 G SAWTH	122 x SAWTH1
059 SINUS	123 SINUS2
060 x VIOLIN	124 VIOL2
061 G HAWAII	125 SIN_HOR
062 x SYNTH 3	126 SINPUL
063 x ORGAN 5	127 DRUMKIT

VOICE 00-29 + 31 : on Panel

VOICE 32-63 : on DIAL

VOICE 64-127 : on DIAL

GLOBAL	
000 Welcome	064 Bossa
001 Love	065 Beguine
002 Vivaldi	066 Joropo
003 C.Basie	067 Porompo
004 Trio	068 EightB.
005 Baroque	069 Sixth.B
006 Steps.A	070 Funk
007 Weather	071 Boogie
008 SuperDX	072 Disco
009 Italy	073 Fusion
010 Church1	074 Blues
011 Church2	075 Dixie
012 Q.Jones	076 Swing
013 ModernQ	077 Waltz
014 12GUITR	078 Polka
015 Stereo	079 March
016 DynaWS	080 Samba
017) B 3 (081 Chacha
018 Piano_E	082 Salsa
019 Cluster	083 Lambada
020 Symphon	084 Song
021 House	085 Soul
022 Metheny	086 Reggae
023 Oscar P	087 Hard
024 RhodVib	088 Rap
025 Syntetx	089 House
026 Split	090 Slow
027 FunkSet	091 Band
028 Pan Pot	092 Take.5
029 Soft	093 JazzW
030 Hendrix	094 Tango
031 SoloSyn	095 Country
032 Free	096 x Bossa
033 x BIRDLND	097 x Beguine
034 x LITTLEW	098 x Joropo
035 empty	099 x Porompo
036 empty	100 x EightB.
037 x ROSANNA	101 x Sixth.B
038 x BACH	102 x Funk
039 x DEBUSSY	103 x Boogie
040 x TUNING	104 x Disco
041 empty	105 x Fusion
042 empty	106 x Blues
043 empty	107 x Dixie
044 empty	108 x Swing
045 empty	109 x Waltz
046 empty	110 x Polka
047 empty	111 x March
048 empty	112 x Samba
049 empty	113 x Chacha
050 empty	114 x Salsa
051 empty	115 x Lambada
052 empty	116 x Song
053 empty	117 x Soul
054 empty	118 x Reggae
055 empty	119 x Hard
056 empty	120 x Rap
057 empty	121 x House
058 empty	122 x Slow
059 empty	123 x Band
060 empty	124 x Take.5
061 empty	125 x JazzW
062 empty	126 x Tango
063 DACTEST	127 x Country

GLOBAL 00-31 : Free Play

GLOBAL 32-63 : SONG PATT.

GLOBAL 64-95 : PROG STYLES

GLOBAL 96-127 : INT. STYLES

Wave VOICE	Wave DRUMKIT
000 ACCORD	000 Agogo Hi
001 BANJO	001 Agogo Lw
002 BASS.ac	002 Bd Gate
003 BASS.el	003 Bd Jazz
004 BASS.fl	004 B.Drum 1
005 BASS.pk	005 Bells
006 BASS.sl	006 Bongo 1
007 BELLS	007 Bongo 2
008 BRASSff	008 Brush 1
009 BRASSpp	009 Brush 2
010 CLA_BRS	010 Brush 3
011 CLA_ORG	011 Cabasa
012 CLA_PUL	012 Claps
013 CLARIN	013 Claves
014 CLAVI	014 Conga 1
015 CLUSTER	015 Conga 2
016 CHOIR	016 Conga 3
017 FLUGELH	017 Conga 4
018 FLUTE	018 Cowbell
019 FMPNOFF	019 Crash 1
020 FMPNOMf	020 Crash 2
021 FMPNOpp	021 El.Tom 1
022 GRANDff	022 El.Tom 2
023 GRANDmf	023 El.Tom 3
024 GRANDpp	024 Guiro
025 GTR.ac	025 HaaVoice
026 GTR.fk	026 HiHat 1
027 GTR.jz	027 HiHat 2
028 GTR.id	028 HiHatFt
029 GTR.pk	029 HiHatOp
030 HAR_ACC	030 Metro 1
031 HAR_SIN	031 Metro 2
032 HARMO	032 Quica Hi
033 HORNS	033 Quica Lw
034 HARP	034 Ride Cy
035 HARPSI	035 RideCup
036 MARIMBA	036 Rim Shot
037 MUT_HOR	037 S.Drum 1
038 MUTED	038 SdFusion
039 OBOE	039 Sd Gate
040 ORG. 1	040 SdJazz 1
041 ORG. 2	041 SdJazz 2
042 ORG. 3	042 Sd Noise
043 ORG. 4	043 Shot
044 ORG. 5	044 Splash
045 PIANOff	045 Tamb Acc
046 PLECTRA	046 TambSoft
047 PUL_ORG	047 TomRmBig
048 PULSE	048 TomRm Hi
049 RHODXff	049 TomRm Lw
050 RHODXpp	050 TomRm Md
051 SAW_PUL	051 Tom1 Hi
052 SAWTH	052 Tom1 Lw
053 SAX.sp	053 Tom1 Md
054 SAX.tn	054 Timba Hi
055 SIN_HOR	055 Timba Lw
056 SIN_PUL	056 Triangle
057 SIN_MUT	057 Vib Slap
058 SINUS	058 Vox Bd
059 STRINGS	059 Vox Boom
060 TROMB.	060 Vox Hoh
061 TRUMPET	061 Vox HH 1
062 VIBES	062 Vox HH 2
063 VIOLIN	063 Vox Spoo

EFF1

EFF2

info

X:
used internal
G:
used only Free Global
numbers:
MIDI-numbers 000-127

Factory Reset:
press Voice 0,1,2,3 &
28,29,30,31
display showing you
MEMORY PUFF

Floppy:
Windows can read the
disk - for archiving etc.