

Model No. SQX-1

Part No. 9920000201

### OPERATING INSTRUCTIONS:

WARNING: The Mirage power switch MUST BE OFF before inserting or removing the cartridge. Failure to turn the power OFF will ruin the cartridge and invalidate the warranty.

The Mirage Sequencer Expander Cartridge increases the memory capacity of the built-in sequencer by 1,024 events. "Events" include key strikes, pitch bend and modulation depth changes. The total capacity of the Mirage sequencer with the Expander Cartridge is 1,357 events. The actual note capacity may be less if the pitch bend and modulation wheels are used during sequence recording.

## Saving and Loading Sequences

Using the Sequencer Expander Cartridge also changes the way that the Mirage saves and loads sequences. The Mirage automatically changes the saving and loading systems when the Expander Cartridge is inserted.

Without the Expander Cartridge, the Mirage will store up to 8 short sequences on an Ensoniq Sound

Diskette or Formatted Diskette, numbered 1 through 8. With the Expander Cartridge, the Mirage will store up to 3 long sequences, numbered 1 through 3.

Saving a long sequence on a diskette which contains short sequences will erase any previously saved short sequences in the following manner:

Long Sequence 1
will erase Short Sequences 4 & 5.
Long Sequence 2
will erase Short Sequences 2, 6 & 7.
Long Sequence 3
will erase Short Sequences 3 & 8.

Saving short sequences on a diskette that contains long sequences will erase any long sequences which overlap.

If you attempt to load a long sequence from a diskette without the Expander Cartridge inserted, you will get a flashing "nc" message in the display informing you that no cartridge is present and that a long sequence cannot be loaded.

## LIMITED WARRANTY

#### What Is Covered

This warranty covers all defects in material and workmanship for thirty days from the date of purchase from an Authorized ENSONIQ Dealer.

#### What Is Not Covered

This warranty does not cover damage to or deterioration of the cartridge or internal circuitry resulting from accident, misuse, neglect, attempted unauthorized repair or failure to follow operating instructions. Inserting the cartridge into the Mirage with the power on could damage the cartridge. This would invalidate the warranty.

### How to Obtain Warranty Performance

Return your defective Sequencer Expander with this package to an Authorized ENSONIQ Dealer along with proof of purchase. The defective Sequencer Expander will be replaced.

# Limitations Of Implied Warranties And Exclusion Of Certain Damages

Any implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty.

ENSONIQ's liability, for any defective product, is limited to repair or replacement of the product.

ENSONIQ shall not be liable under any circumstances for:

- 1. Damages based upon inconvenience, loss of use of the Sequencer Expander, loss of time, interrupted operation or commercial loss.
- 2. Any other damages, whether incidental, consequential or otherwise, except damages which may not be excluded under applicable law.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages so the above limitations and exclusions may not apply to you.

The warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

# NO CLAIM FOR WARRANTY WILL BE HONORED WITHOUT PROOF OF PURCHASE

ENSONIQ FACTORY SERVICE 263 Great Valley Parkway Malvern, PA 19355 (215) 647-3930